

**Sales Model:** 3412  
**Invoice Number:** GEDR5101727

**Dealer:** D100

**S.O. Number:** NMFBR00

**Build Date:** 2002-04-30

---

Feature Codes

<b>Reference Number</b>	<b>Eng Chg</b>	<b>Quantity</b>	<b>ASM</b>	<b>LESS</b>	<b>Set Type</b>	<b>Description</b>
KW00600	F	1	I			600 EKW W/FAN
412DE1N	F	1	I			3412 480/277V 60 HZ
GOVEL11	F	1	I			ELECTRONIC LOAD SHARE GOVERNOR
MNTWB00	F	1	I			WIDE BASE
FUMDIS1	F	1	I			FUMES DISPOSAL
EMCENGU	F	1	I			ENGLISH DISPLAY UNITS
EMCDP01	F	1	I			DUST-PROOF CONTROL PANEL
SHK0001	F	1	I			SPACE HEATER KIT
OPAMSP2	F	1	I			MANUAL SUMP PUMP
EMCCAS1	F	1	I			COMMON ALARM/SHUTDOWN
COLHTR2	F	1	I			JACKETWATER COOLANT HEATER
CNTCT01	F	1	I			CONTACTOR GP
ACLHD13	F	1	I			AIR CLEANER - HEAVY DUTY
60H0480	F	1	I			60HZ 480 VOLTS
MSEPGGN	F	1	I			GENERAL EPG
LITENGE	F	1	I			EXTRA ENGLISH LITERATURE
STANDBY	F	1	I			STANDBY POWER APPLICATION
LANENGO	F	1	I			ENGLISH LANGUAGE OPTION
NONCERT	F	1	I			NOT EPA&CARB NONROAD EMIS CERT
NONULL	F	1	I			NON UL 2200 LISTED PKG GEN SET
2301GOV	F	1	I			2301 GOVERNOR
EMCPTWO	F	1	I			ELECTRONIC MODULAR CONTROL PNL
XLLENGL	F	1	I			EXTRA ENGLISH LITERATURE

---

Part Numbers	Reference Number	Eng Chg	Quantity	ASM	LESS	Set Type	Description	BreakDown
	PP4241	01	1				896 BHP 625 GEN KW WOF 60 HZ S	<a href="#">BreakDown...</a>
	0V2018		1				0V2018 EPG SB PRICEMPGM20-00	<a href="#">BreakDown...</a>
	CA1281	10	1				ENGINE AR-BASIC 3412 DITTA PKG	<a href="#">BreakDown...</a>
	1676897	00	1				GENERAL AR-3412 DITTA GEN SET	<a href="#">BreakDown...</a>
	1668590	03	1				ENGINE AR - BASIC	<a href="#">BreakDown...</a>
	3L0284		1				*****TEST - PKG GEN SET*****	<a href="#">BreakDown...</a>
	3L0303		1				*ADJUSTING-WW 2301 CONTROL SYS	<a href="#">BreakDown...</a>
	3N8594	04	1				COVER GP-ENG/GEN LIFT EYE	<a href="#">BreakDown...</a>
	5P2506	00	1				LITERATURE - ENGLISH	<a href="#">BreakDown...</a>
	6N8878	02	1				FUEL PRESSURE GAUGE	<a href="#">BreakDown...</a>
	7L7871	08	1				24 VOLT BATTERY SET - DRY	<a href="#">BreakDown...</a>
	1195148	01	1				COOLANT-LONG LIFE-BULK-1 LITER	<a href="#">BreakDown...</a>
	1366625	00	1				GENERATOR AR - SR4B	<a href="#">BreakDown...</a>
	1426947	04	1				SENSOR GP-LEVEL-LOW COOLANT	<a href="#">BreakDown...</a>
	1439518	07	1				REGULATOR GP - VOLTAGE	<a href="#">BreakDown...</a>
	1497876	03	1				FASTNER GP-COUPPLING-GENERATOR	<a href="#">BreakDown...</a>
	1497899	02	1				SENSOR GP - ENGINE	<a href="#">BreakDown...</a>
	1517794	04	1				MOUNTING GP-ENGINE-FLEXIBLE	<a href="#">BreakDown...</a>
	3L0432		1				*TEST - PKG GEN SET (EMCP II)*	<a href="#">BreakDown...</a>
	1683241	05	1				ENCLOSURE GROUP	<a href="#">BreakDown...</a>
	1690198	08	1				PANEL GP - EMCP II	<a href="#">BreakDown...</a>
	1690226	03	1				BOX GP - JUNCTION	<a href="#">BreakDown...</a>
	1690240	03	1				COVER GP	<a href="#">BreakDown...</a>
	1690247	09	1				BOX GROUP-BREAKER	<a href="#">BreakDown...</a>
	1690256	05	1				MOUNTING GP-PWR TERMINAL STRIP	<a href="#">BreakDown...</a>

1690296	03	1		CONNECTION GP - GENERATOR	<a href="#">BreakDown...</a>
1692054	08	1		RADIATOR GP	<a href="#">BreakDown...</a>
1694439	04	1		HARNES ASSEMBLY-WIRING SENSOR	<a href="#">BreakDown...</a>
1694441	06	1		HARNES ASSEMBLY- WIREING BASIC	<a href="#">BreakDown...</a>
1694444	04	1		HARNES AS - WIRING - GOV	<a href="#">BreakDown...</a>
1694450	03	1		HARNES ASSEMBLY-WIRING AC	<a href="#">BreakDown...</a>
1803986	02	1		MTG GP - JUNCTION	<a href="#">BreakDown...</a>
1834729	03	1		MOUNTING GP-CONTROL PANEL-REAR	<a href="#">BreakDown...</a>
1560040	00	1		TRANSFORMER GP	<a href="#">BreakDown...</a>
1708400	03	1		COVER GP	<a href="#">BreakDown...</a>
1888215	01	1		GUARD GP - BELT	<a href="#">BreakDown...</a>
1968775	02	1		SWITCH GP	<a href="#">BreakDown...</a>
2042515	00	1		WIRING GP	<a href="#">BreakDown...</a>
2127990	00	1		FITTING GROUP-EXHAUST	<a href="#">BreakDown...</a>
1896394	00	1		CABLE GP - ELECTRIC	<a href="#">BreakDown...</a>
CA1443	02	1		GOVERNOR GP-2301A W/EG3P-LOAD	<a href="#">BreakDown...</a>
1720323	01	1		CONTROL GP-GOVERNOR- LOAD SHARE	<a href="#">BreakDown...</a>
CA2611	00	1		BASE GP-ENGINE	<a href="#">BreakDown...</a>
1683252	02	1		LINES GROUP - DRAIN- COOLANT	<a href="#">BreakDown...</a>
1692069	01	1		LINES GP - FLEX FUEL	<a href="#">BreakDown...</a>
1708402	02	1		BASE GP - ENGINE & GENERATOR	<a href="#">BreakDown...</a>
1988793	00	1		SUPPORT GP - BATTERY	<a href="#">BreakDown...</a>
CA1942	00	1		REMOVAL AR-DISPOSAL GP	<a href="#">BreakDown...</a>
1692120	02	1		DISPOSAL GROUP - FUMES	<a href="#">BreakDown...</a>
CA0846	04	1		ENGLISH DISPLAY UNITS	<a href="#">BreakDown...</a>
1214713	00	1		ENGLISH DISPLAY UNITS	<a href="#">BreakDown...</a>
CA1789	02	1		DUSTPROOF KIT	<a href="#">BreakDown...</a>
1847039	01	1		DUSTPROOF KIT	<a href="#">BreakDown...</a>
CA1445	02	1		HEATER GP-SPACE	<a href="#">BreakDown...</a>
1716842	02	1		CONNECTION GP	<a href="#">BreakDown...</a>
CA1423	02	1		PUMP GP-SUMP-MANUAL	<a href="#">BreakDown...</a>
1683300	01	1		PUMP GP - SUMP	<a href="#">BreakDown...</a>

CA1430	04	1		RELAY GP-COMMON ALARM/SHUTDOWN	<a href="#">BreakDown...</a>
1902565	03	1		HARNES AS	<a href="#">BreakDown...</a>
2000844	01	1		RELAY GP	<a href="#">BreakDown...</a>
CA1389	01	1		HEATER GP-JACKET WATER- 6000 WA	<a href="#">BreakDown...</a>
1683238	02	1		HEATER GROUP - JACKET WATER	<a href="#">BreakDown...</a>
1716841	03	1		CONNECTION GP	<a href="#">BreakDown...</a>
1847031	02	1		CONTACTOR GP	<a href="#">BreakDown...</a>
CA1379	01	1		CLEANER GP-AIR-HEAVY DUTY	<a href="#">BreakDown...</a>
1683295	02	1		CLEANER GP - AIR - HEAVY DUTY	<a href="#">BreakDown...</a>
5N9597		1		VOLTAGE INDICATOR 480V, 60HZ	<a href="#">BreakDown...</a>
0V1065		1		END USE: GENERAL EPG	<a href="#">BreakDown...</a>
0P9715		1		EXTRA LITERATURE - ENGLISH	<a href="#">BreakDown...</a>
9Y8156		1		STANDBY POWER APPLICATION	<a href="#">BreakDown...</a>
CA0866	05	1		LANGUAGE MARKINGS- ENGLISH	<a href="#">BreakDown...</a>
PP4241	01	1		896 BHP 625 GEN KW WOF 60 HZ S	<a href="#">BreakDown...</a>
0K0518	00	1		668 KW @ 1800 RPM (896 BHP)	<a href="#">BreakDown...</a>